


Fixed Temperature


Set a fixed temperature for the thermostat to reach and maintain until you revert back to program mode or switch the heating off.

1



Press menu > Program > Set program > Set fixed temperature.

2




Set the target temperature and press accept.

Temporary Override

Set a temperature you would like the thermostat to reach and the length of time you want this override to last.


1



Press the temperature in the middle of the home screen.

Alternatively press menu > Temperature > Override.

2



Set the target temperature, duration of override and press accept.